

II 、 Introduction to paper cutter

1、 Description of paper cutter components



2.technical parameter

Model	XB-AT551-09EP flagship version2.0
Max cutting length(mm)	495
Min cutting length(mm)	30
Cutting thickness(mm)	83
Cutting precision(mm)	±0.2
Clamping mode	Hydraulic+mechanical pedal
Display	7.0" touch screen
Front platform	3.0mm stainless steel
Power	220V(110V) 50HZ(60HZ) ,1.9KW
Weight	about 330KG
Machine size(L*D*H) mm	1180X850X1370

3. operation panel

◆ Operation diagram of paper cutter

Turn on the power supply, turn on the power switch, turn the switch to on, the display will be on, and the display will show the president's switch,

When the knife light is on, the paper pusher automatically adjusts the size, which indicates that it has entered the normal startup state.

The correct way to operate the machine is to stand in front of the center of the machine and face the paper cutter. The left hand controls the button on the left and the right hand controls the button on the right (you can also step on the pedal switch for single pressure or single pressure before cutting), as shown in the figure.



III 、 Basic operation and adjustment

1. basic operation

◆ Power on

Before starting the machine, check whether there are other articles on the machine, and clean them up;

Turn on the power supply;

Turn the electrical protection switch to the "on" position, turn on the power switch, the NC screen / LCD screen will display, the position indicator line will be on, and the paper pusher will be automatically calibrated, indicating that the power is normal.

